

# General Specifications

GS 01R01A01-01E

FieldMate  
Versatile Device Management Wizard

**FieldMate™ R3.01**

## 1. Features

**FieldMate** is used for the field device setting and adjustment, which must be connected for all activities.

Moreover off line database function for up to 500 devices which maintains a complete record for all device configuration and maintenance activities.

FieldMate is a PC based configuration tool that performs numerous tasks, including initial setup, daily maintenance, troubleshooting, and configuration backup for device replacement. These tasks are streamlined by FieldMate's intuitive operation and integrated environment, which is independent from communication protocols and device vendors.

FieldMate incorporates the open FDT/DTM standard and is compliant with DTM's per the FDT1.2 and FDT2.0 simultaneously standard. FieldMate supports by Built-in DTM interpreting the existing Device Description (DD) instantaneously, for other vendor's devices that do not have DTM's available.

\*FDT: (Field Device Tool) is a frame application that standardizes the communication and configuration interface between all field devices and host systems.

\*DTM: (Device Type Manager) is the application which defines the Graphical User Interface (GUI) specific to the device.

The FDT frame is an integral part of FieldMate. Many DTM's are included with the FieldMate application, and additional DTM's are available from most field device vendors.

## 2. Functional Details

### FieldMate

Segment Viewer
Device Viewer
DTM Works
Parameter Manager
DD Menu
History
3rd Party Device DTM
Device Replacement Tool
Device Navigator
Device Maintenance Info
User Management
3rd Party COMM DTM
Serial Number Acquisition
AXF Verification
PRM Synchronization
FieldMate Validator

F001.ai

### ■ Communication Function

FieldMate supports the following communication protocols:

- **BRAIN**
- **FOUNDATION™ fieldbus H1**
- **HART (HART7 is supported)**
- **PROFIBUS**
- **ISA100.11a**

It conforms to ISA (International Society of Automation) 100.11a which has been progressed as the standards of Wireless system for Industrial Automation.

- **Modbus**

### ■ Device Interface Function

**Segment Viewer:** BRAIN, FOUNDATION fieldbus H1, HART, PROFIBUS, ISA100.11a\*1, Modbus

Displays a list of devices currently connected on the communication lines, grouped by protocol.

Basic device specific information is displayed depending on protocol (Device ID, Manufacturer ID, address, Device type, Device revision, and status)

\*1 It displays either via gateway or infrared communication.



**YOKOGAWA** ♦

Yokogawa Electric Corporation  
2-9-32 Nakacho, Musashino-shi, Tokyo 180-8750, Japan  
Tel: 81-422-52-9714 Fax: 81-422-52-2102

GS 01R01A01-01E  
©Copyright June 2006  
14th Edition Dec. 4, 2015

**Device Viewer: FOUNDATION fieldbus H1, HART**

Displays the current status of the field device, including errors, warnings and good status. The status display icon (red, yellow, green) clearly indicates the device's self-diagnostic status.

**Device Navigator**

Shows all registered devices.

Provide a searching function by tag, device name, memo, etc.

Online registration and offline registration can directly be implemented from Segment Viewer/Device Navigator. (Up to approx. 500 devices can be registered) Marking it with flags to remind users of outstanding issues etc., simplifying daily maintenance.

**■ Configuration Function**

Device parameters can be easily configured.

**● DTM Works: BRAIN, FOUNDATION fieldbus H1 HART, PROFIBUS, ISA100.11a, Modbus**

The DTM Works provides not only configuration, but easy setup, calibration, simulation wizards etc. as defined by the device vendors' DTM.

**● Parameter Manager: FOUNDATION fieldbus H1, HART**

The Parameter Manager is a simple parameter viewing window, in which adjustment and field device replacement can easily be performed. Configuration files may be imported/exported from/to the device easily, and stored on the PC for future needs.

**● DD Menu: FOUNDATION fieldbus H1**

The existing fieldbus DD is utilized to enable function block configuration.

**■ History Function**

Logs of operations are automatically recorded.

- 1) Date & Time
- 2) Device Tag
- 3) Device ID
- 4) User
- 5) Source: DTM works, DD Menu, Parameter Manager, etc.
- 6) Category: Configuration (device parameter change) and System (logs of login, etc.).
- 7) Message: Details log of changes

**■ 3rd Party DTM Function**

This function provides device interface in compliance with FDT standard, enabling the features defined by the device vendor's DTM.

**■ Field Diagnostic Function**

In NAMUR recommendation NE107, alarms are standardized into four status signals (Failure, Function Check, Out of Specification and Maintenance Required), this allows for reliable operation, more efficient planning of maintenance and higher confidence in the instruments operation.

The classification, configuration and status of many device alarms that conform to NE107 can be easily checked, changed and monitored by Field Diagnostic Function.

Communication Protocol:  
FOUNDATION fieldbus H1, PROFIBUS

**● Device Replacement Tool**

Applicable device: HART EJX and EJA series  
: Modbus EJX910

Uploads the device parameters and converts them for use by the replacement device.  
Applicable parameters: Tag, Long Tag, Descriptor, Message, LRV, URV, Unit, Press Damp, Xfer function, etc.

**■ Database Function****● Device Maintenance Info.**

Provides advanced maintenance information consisting of:

- Device Information
- Sticky Note
- Images
- History
- Parameter (All Parameters of Device, ZERO Adjustment Parameters of Device)
- Attachment (Memo, Document, Parameter Manager Data, DTM Data)

All information can be exported / imported.

**■ User management**

Provides simple security and activity logging by allowing users to be defined by a user name and password. The user ID is incorporated as part of the device maintenance history.

**■ 3rd Party COMM DTM support**

Provides advanced connections and communication networking enabling:

- Access PROFIBUS-PA/DP devices
- Access HART devices via PROFIBUS
- Access 3rd Party multiplexers.

User defined communication topology can be saved in FDT project.

**● Serial Number Acquisition**

Applicable device: HART EJX and EJA series  
Acquires serial number of the device and updates it in the Device Maintenance Information. Also exports the following information to a file.

- Serial Number
- Device Tag
- Device ID
- Device Revision
- Model and Suffix Code

**● AXF Verification Tool (/VF option)**

Verifies flowmeters without having to disconnect from a process line. Standard verification and Enhanced verification are available. The Verification result can be printed and stored in the Device Maintenance Information.

Applicable device: HART Magnetic Flowmeter AXF series

Remarks : AM012 Magnetic Flow Converter, CA150  
HANDY CAL (or equivalent device) and Insulation checker are required for Enhanced verification.

**● PRM (Plant Resource Manager) Synchronization**

Synchronizes information between FieldMate and PRM to make use of PRM as a master data base. Bi-directional file transfer operation is supported.

### ● FieldMate Validator (VT option)

This is an option for the N-IO nodes of Yokogawa CENTUM VP/ProSafe-RS. Validation of connection between N-IO node and the field devices is possible by the FieldMate Validator without FCS (Field Control Station)/SCS (Safety Control Station). The N-IO node configuration and input/output validation are also possible without FCS/SCS. This option enables FieldMate to communicate with field devices via N-IO node. (The Device Replacement Tool cannot be used via N-IO node.)

\* FieldMate Validator can be used only while the communication between FCS/SCS and the N-IO node is not established.

\* The I/O configuration data can be exported/imported between FieldMate Validator and CENTUM VP/ProSafe-RS. For that, Microsoft Excel (Excel 2010 32bit/64bit SP2 or later) is required to be installed in the FieldMate Validator PC. And the following software is required to be installed in CENTUM VP/ProSafe-RS system.

CENTUM VP:

- VP6E5000 Engineering Server Function
- VP6E5100 Standard Engineering Function
- VP6E5210 Module-based Engineering Package

ProSafe-RS:


- RS4E5000 Engineering Server Function
- RS4E5100 Safety System Engineering and Maintenance Function
- RS4E5210 I/O List Engineering Package

## 3. Connection Example (for reference)

Sample BRAIN or HART configuration, connecting a pressure transmitter.

[Required Components]

- BRAIN or HART EJA Pressure Transmitter.
- 24 V DC Power supply
- Load Resistor (250Ω ±10%)
- USB FieldMate Modem: BRAIN/HART



F002.ai

## 4. System Requirements

Software Operating Environment		
OS	Windows 8.1 / 8.1 Pro 32bit/64bit Update or later Windows 7 Professional, Home Premium 32bit/64bit SP1 or later *7	
OS Language	English, Japanese, Chinese(simplified), German, French, Russian *8	
Hardware Operating Environment		
	Windows 8.1	Windows 7
PC	IBM PC/AT Compatible	
CPU	Intel ® Core™ i5-2520M or similar specification CPU	
Main Memory	2GB or more	
Hard Disk Drive	8GB or more	
DVD-ROM Drive	Windows 8.1 compatible	Windows 7 compatible
Display	1024×768 or better resolution recommended Windows 8.1 compatible	1024×768 or better resolution recommended Windows 7 compatible
Network port		
	Windows 8.1	Windows 7
BRAIN	Interface	One USB port USB2.0 standard
HART	Modem	USB FieldMate Modem: BRAIN/HART(Yokogawa Option)
FOUNDATION fieldbus H1 *1	Interface	One PCMCIA card slot
	Interface board	PCMCIA-FBUS Series 2 (National Instruments)
	Driver	NI-FBUS Communications Manager 5.0 or later
FOUNDATION fieldbus H1 *1	Interface	One USB port USB2.0 standard
	Interface board	NI USB 8486 (National Instruments)
	Driver	NI-FBUS Communications Manager 5.0 or later
FOUNDATION fieldbus H1 *1	Interface	One USB port USB2.0 standard
	Interface hardware	FFusb (Softing)
	Driver	V1.10.04.00 or later *2
PROFIBUS	Interface	One USB port USB2.0 standard
	Interface card	PROFlusb (Softing)
	COMM DTM & driver	PROFltm V2.11 or later Driver V5.46 or later
	DP/PA coupler	KFD2-BR-A.PA.93 (PEPPERL+FUCHS) 6ES7 157-0AC80-0XA (SIEMENS)
HART	Interface	Bluetooth 2.0
	Modem	VIATOR ® Bluetooth ®Interface: Model 010041(MACTek ®) *3
ISA100.11a *4	Interface	One USB port USB2.0 standard
	Modem	Infrared Adapter :ACT-IR224UN-LN96-LE 9600bps (ACTISYS) *5
	Driver	Version 1.7.0 or later
ISA100.11a *6	Interface	One Ethernet port
	Modem	One USB port USB2.0 standard
	Driver	Isolated RS422/485 USB adaptor SP390A-R2 (BLACK BOX)
	Driver	Version 2.0.0 or later
Login Account		Administrator privilege

- \*1 Interface is selectable
- \*2 The package is provided complete with FieldMate driver from Softing
- \*3 Microsoft supplied Bluetooth stack is used
- \*4 ISA100.11a OOB infrared communication
- \*5 Holder for Infrared Adapter is available (recommended): Gorillamobile Original: GM1 (JOBY, Inc).
- \*6 ISA100.11a communication via gateway
- \*7 FieldMate Validator is supported with Windows 8.1 Pro 64bit and Windows 7 Professional 64bit.
- \*8 FieldMate Validator is supported with an English OS and a Japanese OS.

## 5. Model and Suffix Codes

Field device management software package: FieldMate Release: R3.01

### MODEL, SUFFIX CODES

Model	Suffix Codes	Description	Remarks
<b>FSA111</b>	.....	FieldMate	
License	<b>S</b> .....	Single PC license	License number issued
—	1.....	Always 1	
Language	1.....	Always 1 *2	
Option Code	/B.....	USB FieldMate Modem	BRAIN/HART
	/NF.....	AXF Verification Tool	
	/NT.....	FieldMate Validator *3	For N-IO Node

CD-ROM (FieldMate Software Media): F9197DS \*1

DVD-ROM (Device Files Media): F9197DT \*1

USB FieldMate Modem (BRAIN and HART protocols): F9197UC

- \*1 Replacement disk only
- \*2 With an English Windows OS, FieldMate English can be installed.  
With the following Windows OS, either FieldMate with the following language or FieldMate English can be installed.  
Japanese, Chinese (simplified), German, French, Russian
- \*3 FieldMate Validator software (including user's manual) may be downloaded from Yokogawa web site.  
A display language of FieldMate Validator is English.  
A commercially available USB cable (Connector type of N-IO node : Micro-B) is necessary to connect to N-IO node.

## 6. External View

External view of USB FieldMate modem: BRAIN/HART




Fig. 3: USB FieldMate Modem

Total cable length: Approximately 2.3m

Technical Specifications	USB Interface
SOFTWARE	
USB Interface	USB2.0 standard *1
ELECTRICAL	
Power Supply	System powered by USB Port
Supply Current	40mA@ + 5 V
Pins to Computer	USB Type-A connector
Pins to Device	2-pin, polarity insensitive Mini-grabber test clips. Detachable alligator clips additionally
Output Level (HART)	0.5 + / - 0.1 Vpp trapezoidal wave@1200/2200 Hz
Output Level (BRAIN)	1.0 + / - 0.1 Vpp trapezoidal wave@2400 Hz
Isolation(DC)	1910 VDC between instrument and computer
Isolation(AC)	1350 Vrms (50Hz)
ENVIRONMENTAL	
Operating Temperature	0 °C to 55 °C
Storage Temperature	-40 °C to 70 °C
Storage Humidity	0% to 95% relative humidity
PHYSICAL DIMENSIONS	
Enclosure	83 x 46 x 18 mm, ABS industrial enclosure
Device Interface Cable	190 cm, 2-conductor terminating with two mini grabber clips
USB Cable	27 cm cable terminating in a USB type A connector

\*1: USB2.0 also covers USB1.1

**EMC Conformity Standards    **

- CE Mark  
EN61326-1 Class A, Table1 (Basic immunity test requirement)
- KC Mark  
Registration No: KCC-REM-YHQ-EEN260

**7. Included Items**

FieldMate includes the following items:

\* Software and User's Manual of FieldMate Validator are not included. Please download Software and User's Manual of FieldMate via Yokogawa web site.

**<Product>**

- CD-ROM: FieldMate Software Media
- DVD-ROM: Device Files Media
- USB FieldMate modem: BRAIN/HART w/ cables (optional)

**<Documentation>**

- License number sheet
- Getting Started

Please download User's Manual via Yokogawa web site  
<http://www.yokogawa.com/fld/doc/manual/fld-fieldmate-manual-01en.htm>

**8. Items Contained in Media****■ Items contained in the Media of FieldMate R3.01:**

CD-ROM: FieldMate Media

- FieldMate Program
- USB modem driver

DVD-ROM: Device Files Media

- Device DTM for Yokogawa devices
  - BRAIN
  - FOUNDATION fieldbus H1
  - HART
  - PROFIBUS
  - ISA100.11a
  - Modbus
- Device DTM for the HART devices \*1
- Built-in DTMs (DTM interprets DD and works right straight.)
  - FOUNDATION fieldbus H1
  - HART
  - ISA100.11a
- DD for the FOUNDATION fieldbus H1 devices \*2
- DD for the HART devices \*1

\*1: Devices registered with HART Communication Foundation, some DTM or DD may not be included.

\*2: Devices registered with Fieldbus FOUNDATION, some DD may not be included.

Remarks:

Yokogawa certifies the quality and operability only of DD and DTM which have been registered by Yokogawa.

**9. Compatibility**

Compatibility between FieldMate and Device Files is indicated on the web site at the following URL.

<http://www.yokogawa.com/fld/fieldmate/fld-fieldmate-systemreq-01en.htm#combi>

**10. User Registration**

FieldMate may be installed on a single PC using the license number provided. FieldMate may be used for up to 30 days without registration.

For permanent installation, user registration is required. After registration an Activation Key is provided to the user. User registration may be done on the FieldMate User Registration web site.

<https://voc.yokogawa.co.jp/PMK/>

The items required for user registration are the license number and Hard Disk serial number (Volume Serial Number) of the PC to which FieldMate is installed.

Installation of FieldMate Validator requires activation of FieldMate.

**11. Trademarks**

All brand or product names of Yokogawa Electric Corporation in this document are trademarks or registered trademarks of Yokogawa Electric Corporation.

All other company brand or product names in this document are trademarks or registered trademarks of their respective holders.